SIEMENS 3004



## **Room Thermostat**

RAA40

Adjustable for heating only or cooling only

Room thermostat with manual changeover switch for heating or cooling systems Two-position control Operating voltage AC 24...250 V

Use

The RAA40 room thermostat is used in heating or cooling systems to maintain the selected room temperature.

Typical use:

- Residential buildings
- Light industrial buildings

In conjunction with

- zone valves
- thermal valves

**Functions** 

OFF


Heating

The front of the unit carries a selector with three positions for Heating / OFF / Cooling. In the OFF position, the input voltage is physically separated from the output voltage. If the room temperature falls below the selected setpoint, the heating contact will close (cooling contact open). If the room temperature exceeds the selected setpoint, the heating contact will open and the cooling contact will close but remains inactive because the selector is set to "Heating".

Cooling

Action reversed.

### **Function diagrams**



Room temperature Switching differential Room temperature setpoint Output signal "Heating" or "Cooling"

### **Equipment combinations**

Designation	Type reference	Data sheet
2-way zone valve DN 15	MVE22.15	CA2N4825
2-way zone valve DN 20	MVE22.20	CA2N4825
2-way zone valve DN 25	MVE22.25	CA2N4825
3-way zone valve DN 15	MXE22.15	CA2N4825
3-way zone valve DN 20	MXE22.20	CA2N4825
3-way zone valve DN 25	MXE22.25	CA2N4825
Thermal actuator (suitable for radiator valves VD / VE / VU and 2T)	STE21.1	CA1N4874

### **Technical design**

Key features of the RAA40 room thermostat:

- Two-position control
- Manual switch for Heating / OFF / Cooling
- · Gas-filled diaphragm

### **Adjustments**

The required temperature is selected by a setpoint adjuster on the front of the thermostat.


The setpoint setting range can be mechanically limited by means of setpoint limiter under the unit cover.

### Notes

# Mounting, installation and Commissioning

The room thermostat should be located where the air temperature can be sensed as accurately as possible, without getting adversely affected by direct solar radiation or other heat or refrigeration sources.

Mounting height is about 1.5 m above the floor.



The unit can be fitted to most commercially available recessed conduit boxes or directly on the wall.

Only authorised personnel may open the unit to perform service. (Caution: AC 250 V) The unit must be isolated from the mains supply before opening.



When installing the unit, fix the baseplate first, then hook on the thermostat body and make the electrical connections. Then fit the cover and secure it (also refer to separate mounting instructions).

The thermostat must be mounted on a flat wall.

The local electrical regulations must be complied with.

If there are thermostatic radiator valves in the reference room, set them to their fully open position.

### Maintenance Mechanical design

The room thermostat is maintenance-free.


The diaphragm is filled with environmentally friendly gas.

The thermostat housing is made of plastic.

#### **Technical data**


$\bigwedge$	Operating voltage	AC 24250 V
Power supply	Frequency	50 or 60 Hz
Operational data	Switching differential SD	≤1 K
	Setpoint setting range	830 °C
	Amperage at AC 250 V	0.26 (2) A
Environmental conditions	Operation	to IEC 721-3-3
	Climatic conditions	class 3K5
	Temperature	0+50 °C
	Humidity	<95 % r.h.
	Pollution degree	normal, to EN 60730
	Transport / storage	to IEC 721-3-2
	Climatic conditions	class 2K3/1K3
	Temperature	-20+50 °C
	Humidity	<95 % r.h.
	Mechanical conditions	class 2M2
	Packaging	single packaging / min. order 20 pieces
Norms and standards	<b>C</b> € conformity	
	Low voltage directive	73/23/EEC and 93/68/EEC
	Product standard	EN 60730
	CN474 C-Tick conformity to	
	EMC emission standard	AS/NSZ 4251.1:1994
	Safety standard	II to EN 60730
	Degree of protection	IP30 to EN 60529
	Screw terminals for	2 x 1.5 mm <sup>2</sup> or 1 x 2.5 mm <sup>2</sup> , min. ( 0.5 mm <sup>2</sup> )
	Weight	0.14 kg
	Colour	white, NCS S 0502-G (RAL 9003)

### **Connection diagrams**



- D1 Zone valve or thermal valve
  L Operating voltage AC 24...250 V
  N1 Room thermostat
  S Selector for Heating / OFF / Cooling
  Y Control output "Heating" or "Cooling", AC 24...250 V
  N Neutral
- T Thermostat element (gas-fillet diaphragm)

### Unit



### Baseplate

